

Dear Client,

If you would like to take your own measurements and order your Santi drysuit through a local dealer, it is essential to follow our rules very strict to avoid any potential mistakes in measuring. After you have your measurements taken, please go through them at least twice to see if there are no missing or incorrectly stated numbers.

- Never take your own measurements yourself – they should be taken by another person to make sure all measurements are tight and on correct levels. Ask a member of family or a friend to help you. Stand straight and do not bend over while you are being measured.
- While being measured, stand straight, do not bend in any direction.
- It is important to take the measurements only wearing underwear, close to the body.
- Follow the instruction point by point as the measurements taken incorrectly may influence the final fit of the drysuit or undersuit, especially when you order a made to measure product.
- Use only a tailor measurement tape that has centimeters scale!
- Don't leave any additional measurement allowance – measure as close to the body as possible.
- Use Santi measurement chart to make sure all measurements are completed.
- Watch Santi video for general instruction, but follow this written guideline thoroughly step by step.

Following instruction leads you through the measurement proces also shown in our movie step by step.

1. Measure the head approximately 1 cm above the eyebrows to choose the correct hood size
2. Moving down, measure the neck above the t-shirt line, under the Adam's apple et the end of the neck.
3. Measure the chest in two steps: first measure the chest in rest and then after breathing in the air. Normally the difference should be around 3-5 cm. Make sure the tape does not fall down below the shoulder blades in the back. The measurement should include the butterfly muscles as well.
4. When measuring a woman, take the bust height measurement in the central point starting from the soft neck area, where the neck ends to the bust line in the fullest point.
5. The woman chest area should be measured in the fullest point of the bust, while wearing a bra preferably.
6. Measure the waist area on the belly button level.
7. If a client has a bigger belly, remember to measure the waist line in the widest point on the belly button line.
8. To measure the lady's waist line correctly, use any kind of marker belt and fasten it around the waist line. The female waist line is the narrowest point, which the measured person should appoint by fastening the marker belt by herself. Leave the marker also for 9 and 10 measurement.
9. Measure the lady's back height centrally from the neck spine bone to the waist line marked with the belt
10. Measure the lady's side trunk length from the armpit to the waist line.
11. Take the biceps measurement in the widest point on the loose arm. Make a special note if the client has a visibly athletic figure. In such cast it is advised to measure the biceps also with bend elbow. Ask the measured person to bend and reach with the arm as if reaching to the tank valves. Measure the biceps in such position.
12. Measure the forearm in the widest point. Ask the measured person to bend and reach with the arm as if reaching to the tank valves. Measure the forearm in such position.
13. Measure the wrist between the palm and the wrist bone
14. Measure the inside arm length by asking the measured person to hold one end of the measurement tape in the armpit and take the arm measurement to the wrist. You can use any cardboard or stiff paper sheet and ask the measured person to mark the end of the armpit by putting this under the arm, so that the tape would not go too deep into the armpit.
15. Measure the back shoulders length from one top arm bone to another layering the tape according to the curve of the shoulders.
16. Measure the total arm length from the back neck spine bone to the wrist while the arm is fully stretched.
17. Measure the hips in the fullest point of the buttocks. In case of women it is essential to check if the point below the buttocks at the thigh area is not wider. It is easy to verify by making a loop from the tape and move it up and down to see if the thighs fit into the loop. This is to allow smooth donning of the suit later through the thighs area.
18. Measure the thigh in the widest point approximately 5 cm from the crotch area. The person with athletic figure should have the thigh measured in slight squat, to strain the muscles.
19. To measure the inner leg, hold one end of the measurement tape in the convenient place in the crotch and measure to the heel end, to the floor. During this measurement determine also the knee positioning and give also measurement (point 26 in numbers sheet). Do not put the tape very deep into the crotch area (same as in case of the inner arm instruction). The measurement needs to be taken without shoes on.
20. Calf measurement is taken in 3 places: first measure the calf in the widest point,
21. Next, measure the height 20 cm from the floor and take the measurement on this level,
22. Next, measure the height from the widest point of the calf to the floor.
23. Measure the ankle on the ankle bone

24. To measure the body trunk, standing straight, hold one end of the tape on the central point of the neck end and lead the tape across the crotch to the back. Mark the place where tape ends and measure the rest of the line to the spine neck bone. Make sure the tape is lead close to the body including all the curves of the body
25. Place the measurement tape on the floor and step on it to determine the length of your foot. Give the measurement in centimeters. This measurement allows to choose the best boots size. Do not put information of your boots size you normally wear, as this might differ depending on the shoe type.

Make sure you have taken all the measurements required by Santi measurement chart. Double-check all measurements for precaution!

Look up in the size chart for the best size from our size range or simply provide your measurements for a made to measure production of the suit.

Visit [santidiving.com](https://santidiving.com/getting-right-size,33,en) for the measurements instruction video: <https://santidiving.com/getting-right-size,33,en>

Ladies Drysuits & Undersuits

Damskie Skafandry i Ocieplacze

SIZE	XS	S	SL	M	ML	MLL	LS	L	LL	XLS	XL	XXL
HEIGHT	156-160	156-160	162-166	162-166	168-172	174-178	162-166	168-172	174-178	168-172	174-178	180-184
CHEST	80-84	86-90	86-90	92-96	92-96	82-96	98-102	98-102	98-102	104-108	104-108	110-114
INNER ARM	48	48	50	50	52	54	50	52	54	52	54	56
BICEPS	26.5	28	28	29.5	29.5	29.5	31	31	31	32.5	32.5	34
FORE-ARM	23	24	24	25	25	25	26	26	26	27	27	28
WAIST	66-70	72-76	72-76	78-82	78-82	78-82	84-88	84-88	84-88	90-94	90-94	96-100
HIPS	86-90	92-96	92-96	98-102	98-102	98-102	104-108	104-108	104-108	110-114	110-114	116-120
INNER LEG	76	75.5	79	79	82.5	86	78.5	82	85	81.5	85	88
THIGH	52	55	55	58	58	58	61	61	61	64	64	67
CALF	35.5	36.5	36.5	37.5	37.5	37.5	39	39	39	40	40	41.5
BACK LENGTH	39	39	40.5	40.5	42	43.5	40.5	42	43.5	42	43.5	45
BODY TRUNK	137	139	143	145	149	153	148	152	156	154	158	165

All measurements in cm. Person who takes the self-measurements takes full responsibility for their result and potential discrepancies.

Wszystkie rozmiary w cm. Osoba ściągająca miarę bierze odpowiedzialność za jej rezultat i ewentualne niezgodności.



Drysuit Form

Formularz zamówień

Name
Imię

Surname
Nazwisko

Address
Adres

City
Miasto

Postcode
Kod

Country
Kraj

Telephone
telefon

e-mail
e-mail

Company
Firma

Address
Adres

EU VAT No.
numer VAT

Notes
Uwagi



Size Rozmiar <input type="checkbox"/> MTM MTM	standard size <input type="checkbox"/> regular luźny <input type="checkbox"/> slim dopasowany	standard size <input type="checkbox"/> regular luźny <input type="checkbox"/> slim dopasowany	standard size <input type="checkbox"/> regular luźny <input type="checkbox"/> slim dopasowany
Colour Kolor B black czarny G gray szary S silver srebrny F fuchsia fuksja L lime limonka A arctic blue arktyczny błękit T turquoise turkus	body trunk tors <input type="checkbox"/> B <input type="checkbox"/> G side gores kliny <input type="checkbox"/> B <input type="checkbox"/> G <input type="checkbox"/> S piping lamówka <input type="checkbox"/> S <input type="checkbox"/> F <input type="checkbox"/> L	body trunk tors <input type="checkbox"/> B side gores kliny <input type="checkbox"/> B <input type="checkbox"/> F <input type="checkbox"/> L	body trunk tors <input type="checkbox"/> A <input type="checkbox"/> T details dodatki <input type="checkbox"/> G collar kołnierz <input type="checkbox"/> B <input type="checkbox"/> G
Zipper Zamek <input type="checkbox"/> plastic plastik <input type="checkbox"/> metal metal	<input type="checkbox"/> left lewy <input type="checkbox"/> right prawy	<input type="checkbox"/> left lewy <input type="checkbox"/> right prawy	<input type="checkbox"/> left lewy <input type="checkbox"/> right prawy
Knee pads Łaty <input type="checkbox"/> none brak	<input type="checkbox"/> yes: Kevlar tak: Kevlar	<input type="checkbox"/> yes: Kevlar tak: Kevlar	<input type="checkbox"/> yes: Kevlar tak: Kevlar

Drysuit Form

Formularz zamówień

Details

Szczegóły

<p>Hood Kaptur</p>	<p><input type="checkbox"/> none brak</p> <p><input type="checkbox"/> yes tak</p> <p><input type="checkbox"/> S <input type="checkbox"/> M <input type="checkbox"/> L <input type="checkbox"/> XL <input type="checkbox"/> XXL</p> <p><input type="checkbox"/> 6mm stitched <input type="checkbox"/> 2x5mm <input type="checkbox"/> 6mm standard <input type="checkbox"/> 6mm collar <input type="checkbox"/> 6mm standard for full face mask <input type="checkbox"/> 6mm collar for full face mask <input type="checkbox"/> 9mm standard <input type="checkbox"/> 9mm collar</p>	<p>pValve Halcyon pValve Halcyon</p>	<p><input type="checkbox"/> none brak</p> <p><input type="checkbox"/> yes tak</p> <p><input type="checkbox"/> left lewa <input type="checkbox"/> right prawa</p>
<p>Neck seal Kryza szyjna</p> <p>cm</p> <p>neck circut obwód szyi</p>	<p><input type="checkbox"/> neoprene neoprenowa</p> <p><input type="checkbox"/> neoprene + insulation neoprenowa + docieplenie</p> <p><input type="checkbox"/> latex + insulation lateksowa + docieplenie</p> <p><input type="checkbox"/> silicone + quick neck silikonowa + quick neck</p>	<p>Rings Pierścienie</p>	<p><input type="checkbox"/> none brak</p> <p><input type="checkbox"/> SANTI Smart Seals SANTI Smart Seals</p> <p><input type="checkbox"/> SiTech SiTech</p> <p><input type="checkbox"/> normal <input type="checkbox"/> oval <input type="checkbox"/> antares</p> <p><input type="checkbox"/> KUBI KUBI</p> <p><input type="checkbox"/> 80mm</p>
<p>Embroidered patch with name Haft z imieniem</p>	<p><input type="checkbox"/> none brak</p> <p><input type="checkbox"/> on left pocket na lewej kieszeni</p> <p><input type="checkbox"/> stitched naszywka <input type="checkbox"/> velcro rzep</p>	<p>Wristseals Manszety</p> <p>cm</p>	<p><input type="checkbox"/> bottle HD butelkowe HD</p> <p><input type="checkbox"/> silicone *only with rings silikonowe *tylko z pierścieniami</p> <p><input type="checkbox"/> cone regular stożkowe</p>
<p>Inflation valve Zawór dodawczy</p>	<p><input type="checkbox"/> Apeks Apeks</p> <p><input type="checkbox"/> SiTech SiTech</p>	<p>Boots Buty</p> <p>size</p>	<p><input type="checkbox"/> standard Neoprene standardowe Neoprenowe</p> <p><input type="checkbox"/> Flex Sole Flex Sole</p> <p><input type="checkbox"/> Neoprene socks Skarpety neoprenowe</p> <p><input type="checkbox"/> + rockboots /option + rockbooty /opcja</p>
<p>Exhaust valve Zawór upustowy</p>	<p><input type="checkbox"/> Apeks low profile Apeks niski profil</p> <p><input type="checkbox"/> Apeks high profile Apeks wysoki profil</p> <p><input type="checkbox"/> SiTech SiTech</p>		